

Multi-Max door securement

The Multi-Max doors should have both lockrod handles secured prior to moving loaded rail cars.

The center hasp is not intended as a primary lock, but only as a failsafe to prevent doors from swinging freely in the event that the lockrod handles are not properly secured.

The image below shows where to apply locks to the lockrod handles.

